



PT. SMART CAKRAWALA AVIATION

WORK ORDER

Form: SCA/MTC/030

Subject :	No.	WO/108-SNM/XI/2022
Inspection Document 10 & Add Task	Date	17 Nov 2022
	A/C Reg.	PK-SNM C208-00655
Reference :	Prepared By	TS
MP C208B Rev. 12	Checked By	CI
	Approved By	TM

To : Engineer In Charge

Description :

1. Perform Inspection Document 10 & Add Task
2. Make an entry in Maintenance Log.
3. Return the Completed Work Order and Form to PPC.

#If any finding, please close the routine card, and transferred to inspection card.

Additional Work :

Compliance Statement	Sign & Date Company Lic. No.: (Engineer In Charge)	Signature (Technical Manager)
----------------------	--	--------------------------------------

AIRCRAFT CHECK WORK SUMMARY

(Form: SCA/MTC/051)

DATE OF ISSUED	JO/WO #	TYPE OF MAINTENANCE	DATE OF ACCOMPLISHED
17 Nov 2022	WO/108-SNM/XI/2022	Inspection Doc. 10 & Add Task	

A/C Type	Mfg. Serial Number	A/C Registration
C208	C208-00655	PK-SNM

AIRCRAFT DATA

Subject	Pos #	Serial Number (SN)	TTSN/TCSN
Engine	#1	PCE-PC2316	
	#2	-	
Propeller/Rotor	#1	190085	
	#2	-	
Landing Gear	NLG		
	LH MLG		
	RH MLG		

PACKAGE COVERED

No	Subject	Qty	Remark
1	Non-Routine Card	2	#001, #002
2	Inspection Card	1	
3	Work Order	1	
4	Summary Inspection List	1	
5	Material and Tool List	-	
6	Escalation form	-	
7	CRS (SMI / Unscheduled Maintenance)	1	

INSPECTION CARD (IC) LIST (Finding during maintenance)

No	Taskcard Ref	Subject	Status		Name/ Sign & Stamp
			Open	Close	
IC-001					
IC-002					
IC-003					
IC-004					
IC-005					
IC-006					

<u>IC-007</u>					
<u>IC-008</u>					
<u>IC-009</u>					
<u>IC-010</u>					
<u>IC-011</u>					
<u>IC-012</u>					
<u>IC-013</u>					
<u>IC-014</u>					
<u>IC-015</u>					

Prepared by :
Technical Support



Hani

Checked by :
Chief Maintenance



Dodit

Verified by :
Chief Inspector



Yanuar

Approved by :
Technical Manager



Istiono



SUMMARY INSPECTION ITEMS
(Form: SCA/MTC/050)

WO Ref: WO/108-SNM/XI/2022

NO.	TASK CARD NO.	DESCRIPTION	DATE	EST MHR	NAME	STAMP
1	B02	PT6A-114A ENGINE GROUND RUN PERFORMANCE				
2	CHAPTER 13	INSPECTION DOCUMENT 07				
3	CHAPTER 14	INSPECTION DOCUMENT 08				
4	CHAPTER 15	INSPECTION DOCUMENT 09				
5	CHAPTER 16	INSPECTION DOCUMENT 10				
6	NRC-001	REPLACE VACUUM SYSTEM CENTRAL AIR FILTER DISCARD P/N: C294502-0201 OR AAD9-18-1				
7	NRC-002	REPLACE VACUUM RELIEF VALVE FILTER DISCARD P/N: C482001-0202 OR B3-5-1				
8	SCA/MTC/023	EMERGENCY EQUIPMENT CHECKLIST				



PT. SMART CAKRAWALA AVIATION

CERTIFICATE RETURN TO SERVICE

SCHEDULED MAINTENANCE INSPECTION

(CRS-SMI)

A/C TYPE	: CESSNA 208		TTSN	:															
A/C REG	: PK-SNM		TCSN	:															
MSN	: C208-00655		DATE	:															
TYPE OF INSPECTION		: INSPECTION DOCUMENT 10 & ADD TASK																	
DUE AT		: 3954 HOURS																	
REFF		: MP C208/C208B REV. 12																	
EXCEPTION																			
<p style="text-align: center;">AUTHORIZED PERSON</p> <p>I hereby certify that this aircraft has been maintained accordance with CASR and Maintenance Program. Aircraft safe and airworthy for flight</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center; padding: 5px;">NAME</th> <th style="text-align: center; padding: 5px;">CAT</th> <th style="text-align: center; padding: 5px;">AMEL/OTR NO</th> <th style="text-align: center; padding: 5px;">SIGN&STAMP</th> <th style="text-align: center; padding: 5px;">DATE</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 10px;"></td> <td style="text-align: center; padding: 10px;">AIRFRAME & POWER PLANT</td> <td style="text-align: center; padding: 10px;"></td> <td style="text-align: center; padding: 10px;"></td> <td style="text-align: center; padding: 10px;"></td> </tr> <tr> <td style="text-align: center; padding: 10px;"></td> <td style="text-align: center; padding: 10px;">EIRA</td> <td style="text-align: center; padding: 10px;"></td> <td style="text-align: center; padding: 10px;"></td> <td style="text-align: center; padding: 10px;"></td> </tr> </tbody> </table>					NAME	CAT	AMEL/OTR NO	SIGN&STAMP	DATE		AIRFRAME & POWER PLANT					EIRA			
NAME	CAT	AMEL/OTR NO	SIGN&STAMP	DATE															
	AIRFRAME & POWER PLANT																		
	EIRA																		
THE NEXT DUE TYPE OF INSPECTION		:																	
DUE AT		:																	

	INSPECTION CARD (Form: SCA/MTC/ 048)				TECHNICAL DEPARTMENT			
1. CARD #	2. JO/WO #	3. ORIGINATOR	4. CARD REF	5. DATE				
6. A/C REG/MSN	7. A/C TYPE	8. TRADE	12. VENDOR ORDER #					
9. ZONE	10. STA	11. MTC TYPE						
13. DESCRIPTION/DEFECT-IF FINDING OF CPCP INSPECTION, PLEASE COMPLETE SET. 20						14 PPC/ENG	15 DATE	
16. CORRECTIVE ACTION						17 MECH	18 ENG. LIC	19 DATE
Performed at A/C TT : A/C TC /LDG :								
20. CORROSION INFORMATION								
LOCATION			CAUSE OF DAMAGE					
			<input type="checkbox"/> Environment					
			<input type="checkbox"/> Internal Leakage					
CORROSION <input type="checkbox"/> Isolated <input type="checkbox"/> Widespread			<input type="checkbox"/> Chemical Spill					
CORROSION LVL <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3			<input type="checkbox"/> LAV/Galley Spill					
PROPOSED ACTION <input type="checkbox"/> Doublers			<input type="checkbox"/> Blocked Drain					
<input type="checkbox"/> Others			<input type="checkbox"/> Wet Insulation Blanket					
			<input type="checkbox"/> Other					
21. If the defect is RII, Please Sign this card finally by RII Inspector						INSP	DATE	
NOTICE OF INSPECTOR								
22. PARTS REQUIRED								
PART DESCRIPTION		PART NO		QTY	SERIAL NO		STATUS	
				ON	OFF		CLOSE	OPEN



MAINTENANCE PROGRAM

CESSNA C208/C208B

Appendix B02 – PT6A-114A Engine Run Performance Sheet

Reg. Mark : PK - SNM

WO/FML No. :

PRE – INSPECTION	
Location	
Date	
Cycle	
Filed Barometric	
OAT	
Altitude	

POST – INSPECTION	
Location	
Date	
Cycle	
Filed Barometric	
OAT	
Altitude	

PRE – INSPECTION		
	Target	Actual
Tq		
Np		
ITT	°C	°C
Ng	%	%
Wf		
Oil Press		°C
Oil Temp		°C
Start Temp		°C

POST – INSPECTION		
	Target	Actual
Tq		
Np		
ITT	°C	°C
Ng	%	%
Wf		
Oil Press		°C
Oil Temp		°C
Start Temp		°C

Engine Run Up Checks													
Inertial	<input type="checkbox"/>	EPL	<input type="checkbox"/>	OVG	<input type="checkbox"/>	Stby Alt	<input type="checkbox"/>	BOV	<input type="checkbox"/>	Brake	<input type="checkbox"/>	Randown	<input type="checkbox"/>
NOTE:													
1. Inertial Separator at Torque 400 ft-lbs.		3. EPL check can't exceed 4% Ng per second.		5. Low idle at 52.5 – 53.5% 40Amps.		2. Standby Alt at 80% Ng.		4. Standby Alt at 80% Ng.		6. High idle at 64 - 66% Ng 40Amps.			

Engine Performance Target Table Cessna C208

OAT (°C)	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41
Tq (ft.lbs)	1865	1865	1865	1865	1865	1865	1865	1865	1865	1865	1865	1865	1865	1865	1865
Np	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900	1900
ITT (°C)	772	775	778	780	785	790	793	795	797	800	800	800	802	805	810
Ng (%)	98.5	98.5	99	99	99.1	99.2	99.4	99.5	99.5	100	100	100.2	100.5	100.7	100.9
WF (PPH)	450	450	450	450	450	450	450	450	450	450	450	450	448	448	446

Note:

1. Make sure that inertial separator in normal condition, no bleed air extracted from the engine and air condition OFF.
2. This table only applies to altitude 0-500 feet MSL. For higher altitude, refer to EMM 72-00-00.
3. Max fuel flow is 465 lb/hr fuel flow is not more than 15 lbs/hr higher than the value shown in table.
4. If parameters are outside the target performance table to EMM chapter 71-00-00.

REMARKS:

PERFORMED BY			
Name	Sign & Stamp	Date	Location



NON ROUTINE CARD
(Form: SCA/MTC/047)

1. JO/WO #	2. DATE	3. MTC TYPE	4. A/C REG/MSN
WO/108-SNM/XI/2022		REPLACEMENT	PK-SNM/208-00655
5. CARD #	6. ATA SPEC	7. TRADE	8. STA
#001	37		
9. ZONE	10. PANEL		

11. DESCRIPTION

PERFORM REPLACE VACUUM SYSTEM CENTRAL AIR FILTER DISCARD
PN: AAD9-18-1

REFERENCE	<input checked="" type="checkbox"/> AMM Ch. 37-10-00-960	<input type="checkbox"/> EMM Ch	<input type="checkbox"/> OTHER
RII (*)	<input type="checkbox"/> Y	<input checked="" type="checkbox"/> N	MHR :

12. RESULT				MECH	ENG	INSP (*)
Performed at A/C TT : A/C TC /LDG :						
FINDING	<input type="checkbox"/> Y	<input type="checkbox"/> N	ACT MHR :	DATE/TIME (DD/MM/YY)		
INSPECTION CARD (IC) #						

13. PARTS REQUIRED

DESCRIPTION	PART NO	QTY	REMARK	
			STOCK	STATUS

14. TOOLS REQUIRED

DESCRIPTION	PART NO / MODEL	NEXT CALIBRATION DATE	STATUS



NON ROUTINE CARD
(Form: SCA/MTC/047)

1. JO/WO #	2. DATE	3. MTC TYPE	4. A/C REG/MSN
WO/108-SNM/XI/2022		REPLACEMENT	PK-SNM/208-00655
5. CARD #	6. ATA SPEC	7. TRADE	8. STA
#002	37		
9. ZONE	10. PANEL		

11. DESCRIPTION

PERFORM REPLACE VACUUM RELIEF VALVE FILTER DISCARD

PN: B3-5-1

REFERENCE	<input checked="" type="checkbox"/> AMM Ch. 37-10-00-961	<input type="checkbox"/> EMM Ch	<input type="checkbox"/> OTHER
RII (*)	<input type="checkbox"/> Y	<input checked="" type="checkbox"/> N	MHR :

12. RESULT

MECH ENG INSP (*)

Performed at A/C TT : A/C TC /LDG :

FINDING	<input type="checkbox"/> Y	<input type="checkbox"/> N	ACT MHR :	DATE/TIME (DD/MM/YY)
INSPECTION CARD (IC) #				

13. PARTS REQUIRED

DESCRIPTION	PART NO	QTY	REMARK	
			STOCK	STATUS

14. TOOLS REQUIRED

DESCRIPTION	PART NO / MODEL	NEXT CALIBRATION DATE	STATUS

VACUUM DISTRIBUTION - INSPECTION/CHECK

1. General

A. This section has the inspections and checks necessary to keep the vacuum distribution system in a serviceable condition.

TASK 37-10-00-960

2. Vacuum System Central Air Filter Discard

CAUTION: Do not operate the vacuum system with the filter removed or a vacuum line disconnected. Dust and other foreign objects can enter the system and damage the vacuum operated instruments.

A. General

(1) This task gives the instructions to discard the vacuum system central air filter.

B. Special Tools

(1) None

C. Access

(1) None

D. Discard the Vacuum System Central Air Filter.

(1) Remove the vacuum system central air filter. Refer to Chapter 12, [Vacuum System Central Air Filter - Servicing](#).
(a) Discard the filter.

(2) Install a new vacuum system central air filter. Refer to Chapter 12, [Vacuum System Central Air Filter - Servicing](#).

E. Restore Access

(1) None

END OF TASK

TASK 37-10-00-961

3. Vacuum Relief Valve Filter Discard

CAUTION: Do not operate the vacuum system with the filter removed or a vacuum line disconnected. Dust and other foreign objects can enter the system and damage the vacuum operated instruments.

A. General

(1) This task gives the instructions to discard the vacuum relief valve filter.

B. Special Tools

(1) None

C. Access

(1) None

D. Discard the Vacuum Relief Valve Filter.

(1) Get access to the relief valve behind the attitude gyro.
(2) Carefully stretch the foam element filter over the top of the retaining bezel.
(3) Remove the filter from the relief valve and discard it.
(4) Stretch a new relief valve filter over the top of the retaining bezel.
(5) Make sure that the filter is secure on the relief valve.

E. Restore Access

(1) None

END OF TASK

VACUUM SYSTEM CENTRAL AIR FILTER - SERVICING

1. General

A. The vacuum system central air filter keeps dust and dirt from entering the vacuum operated instruments.

CAUTION: Do not operate vacuum system with filter removed or vacuum line disconnected, as dust and other foreign matter may enter the system and damage the vacuum operated instruments.

B. Refer to [Chapter 5, Inspection Time Limits](#) for filter inspection intervals. Replace filter element when damaged and whenever it becomes sufficiently clogged to cause suction gage reading to drop below 4.5 inches Hg (mercury).

CAUTION: Smoking during system operation will cause premature filter clogging.

2. Servicing

A. Remove Air Filter (Refer to [Figure 301](#)).


- (1) Unscrew bolt and washer from bottom of central air filter.
- (2) Remove central air filter from filter bracket.
- (3) Inspect for damage, deterioration and contamination. Clean or replace as required.

B. Install Air Filter (Refer to [Figure 301](#)).

- (1) Seat central air filter up and into filter bracket.
- (2) Secure central air filter to filter bracket using bolt and washer.
- (3) Check central air filter for unobstructed flow. A properly functioning filter should allow a reading of at least 4.5 inches Hg (mercury) on the instrument panel suction gage.

Figure 301 : Sheet 1 : Vacuum System Central Air Filter Servicing

A22863



26141069



**EMERGENCY EQUIPMENT
LIST
INSPECTION & MONITOR**

**PT. SMART CAKRAWALA
AVIATION
DEPARTMENT TEKNIK
Form: SCA/MTC/023**

DATE :	A/C REG : PK-SNM	
A/C TYPE : C 208	CHECKER :	SIGN:

No.	Description	P/N	S/N	Next Insp.	Remarks
1	Pilot Life Vest				
2	Co-Pilot Life Vest				
3	Pax Life Vest				
4	Pax Life Vest				
5	Pax Life Vest				
6	Pax Life Vest				
7	Pax Life Vest				
8	Pax Life Vest				
9	Pax Life Vest				
10	Pax Life Vest				
11	Pax Life Vest				
12	Pax Life Vest				
13	Firt Aid Kit				
14	Crash Axe Installed				
15	Fire Extinguisher				
16	Life Raft (If Installed)				
17	Survival Kit (If Installed)				
OTHERS					



Additional Work Sheet

Inspection Doc. 10 & Add Task

Aircraft Registration: **PK-SNM**

WO# Nr: WO/108-SNM/XI/2022

Parts Used Sheet

1

Special Tool Used



Additional Work Sheet

Inspection Doc. 10 & Add Task

Aircraft Registration: **PK-SNM**

WO# Nr: WO/108-SNM/XI/2022

Parts Used Sheet

2

Part Used