



MAINTENANCE PROGRAM CESSNA C208/C208B

Chapter 44 – Engine PT6A-114A 100 Hours/Minor Inspection

Reg. Mark	:	PK - _____	Date	:	_____
MSN	:	_____	Station	:	_____
TSN / CSN	:	_____	WO No.	:	_____

ITEM CODE NO.	ZONE	TASK	SIGNATURE	
			SIGN	STAMP
E710001	130	Do a check of the FCU manual override system for static operation.		
E710003	130	Do a compressor performance recovery wash.		
E710004	130	Inspect all accessible connections, clamps and brackets for attachment. Inspect accessible lockwire and safety cable for security and installation.		
E710005	130	Inspect of wear, chafing, cracks and corrosion for tubing, wiring, control linkage, hose assemblies. NOTE: Visually inspect insulated air tubes for signs of swelling, cracking, bulging of rubber sheath material. Refer to repair section and SB1687 . Replace as necessary.		
E710006	130	Examine linkages. Pay particular attention to rear linkage cam box, fuel control unit arm, telescopic rod and rod end fittings. Disconnect rod ends and clean using solvent (PWC11-027) or (PWC11-031). Lubricate with light grease (PWC04-001) after engine external wash. Examine rod end for corrosion, roughness in rotation, side play and radial play. After lubrication reinstall rod ends and torque to specified value (Ref 76-10-00). Check free movement of linkage.		
E710007	130	Inspect attachment and linkages, air, oil and fuel lines (Ref. 73-10-07/-08). NOTE: Visually inspect insulated air tubes for signs of swelling, cracking, bulging of rubber sheath material. Refer to repair section and SB1687 . Replace as necessary.		
E710011	130	Performed Deceleration Check		
E720001	130	Do a visual inspection of the engine exhaust duct welds.		
E720002	130	Do a visual inspection of the engine exhaust duct for cracks.		
E720003	130	External surfaces, and fireseal mount ring brackets for cracks, distortion, and corrosion of gas generator case (Ref. 72-30-04).		

Chapter 44 – Engine PT6A-114A 100 Hours/Minor Inspection

ITEM CODE NO.	ZONE	TASK	SIGNATURE	
			SIGN	STAMP
E722001	130	Do a visual inspection of the air inlet screen.		
E722004	130	Cracks and attachment of brackets and seals of fireseal mount rings. (Ref. 72-30-01/-02)		
E723000	130	Do a visual inspection with a mirror or a borescope inspection of the First-stage Compressor Rotor and the inlet case for corrosion		
E731002	130	Do a visual inspection of the fuel pump (in-situ inspection only) for installation and leakage		
E731003	130	Check oil-to-fuel heater installation		
E731014	130	Check starting flow control/flow divider for installation and leaks.		
E731015	130	Check outlet filter for foreign matter or distortion (Ref. 73-10-02). (CLEANING / REPLACEMENT) P/N OFF: _____ P/N ON: _____		
E731006	130	Check drain valve for installation and leaks		
E731008	130	Do a visual inspection of the P3 filter and drain valve.		
E731018	130	Clean or replace the P3 filter based on condition, service experience or environment. Note: If corrossions are found, replace filter.		
E732001	130	Check FCU for installation, linkages and pneumatic tubes.		
E732002	130	Examine the FCU for bearing wash-out, shown by blue dye (grease and fuel mixed) at FCU vent.		
E792002	130	Oil filter elements and secondary screen (coarse hat-type screen attached to the inner end of the filter).		
E792003	130	Examine the forward oil transfer elbow installation on the Flange A. Make sure that the bolts tighten correctly		
*** End of Engine PT6A-114A 100 Hours Inspection Items ***				



MAINTENANCE PROGRAM CESSNA C208/C208B

Chapter 44 – Engine PT6A-114A 100 Hours/Minor Inspection

PERSONNEL PARTICIPATING IN THIS INSPECTION			
NAME	POSITION	SIGNATURE	LICENSE NUMBER

RETURN TO SERVICE

The work recorded above has been carried out in accordance with the requirements of the Civil Aviation Safety Regulation for the time being in force and in that respect the aircraft is considered fit for Release to Service.

Name : _____ Stamp : _____
Signature : _____ Place/Date : _____